

QUICK REFERENCE GUIDE (CD PLAYER)

The USB CD player is a conversion unit that is designed to communicate with the applicable vehicle's USB processing HUB. Each processing HUB in your vehicle has a buffered memory, which is designed to hold a small amount of information from the media file to ensure smooth playback. It is important to understand this process and how it works to ensure full customer satisfaction and proper operation.

PLEASE MAKE SURE YOU HAVE ORDERED THE PROPER PLAYER FOR YOUR APPLICATION. PLEASE REFER TO THE APPLICATION GUIDE FOR MODEL FITMENT.

Step 1: Connect unit to the USB port delegated for data and not for only phone charging.

Step 2: Confirm the radio is in the ON position then proceed to select USB1 or USB2 on your radio (depending on which port you occupy).

NOTE: THE UNIT MAY NOT BE FOUND BY THE FACTORY RADIO UNTIL A CD HAS BEEN INSERTED INTO THE PLAYER. THIS CAN TAKE 10-20 SECONDS AFTER THE DISC HAS BEEN INSERTED.

Step 3: Once the disc is inserted you will need to wait at least 10-30 seconds for the USB HUB in the vehicle to acquire the CD information completely. Although the CD has begun playing, you MUST wait for this to complete to avoid potential issues. NOTE: If this process is interrupted in any way, erratic playback can take place. Some USB HUBs are sensitive to this procedure. If you have interrupted the process, simply remove the disc you are attempting to play and insert an entirely new disc. This will reset the vehicle's USB HUB memory and allow a fresh start.